

- Glove box
- 2 Auxiliary boxes (if equipped)
- **B** Bottle holders
- Cup holders
- **5** Console box

Glove box

The glove box can be opened by pressing the lock release button and locked and unlocked using the mechanical key.



Press the button.



- 1 Lock
- 2 Unlock

n Trunk opener main switch

The trunk opener main switch is located in the glove box. $(\rightarrow P. 60)$




A CAUTION

n Caution while driving

Keep the glove box closed when not in use. In the event of sudden braking, an accident may occur due to an occupant being struck by the open glove box or the items stored inside.

Console box



Pull up the knob to release the lock and slide the armrest.



Pull up the knob to release the lock and lift the armrest.

${\rm n}\,$ When using the console box lid as an armrest



Pull up the knob to release the lock.



Slide the armrest lid forward.

n Coin holder in the console box



n Routing accessory device cables



A CAUTION

n Caution while driving

Keep the console box closed when not is use. In the even of sudden braking, an accident may occur due to an occupant being struck by the open console box or the items stored inside.


Cup holders

Front




Press down and release the left side of the cup holder lid.

Rear



Pull the armrest down.



Lift the lid.

n Using the cup holder to store small items



Remove the holder.

n The position of the holder can be changed (front)



Change the position of the holder.

A CAUTION

n Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking, causing injury. If possible, cover hot drinks to prevent burns.

n When not in use

Keep the cup holders closed. In the event of sudden braking, an accident may occur due to an occupant being struck by the open cup holders or the items stored inside.



n To prevent damage to the rear cup holders

Stow the cup holders before stowing the armrest.

Bottle holders

Front



Rear



- 1 When storing a bottle, close the cap.
- $1 \ \ \, \text{The bottle may not be stored depending on its size or shape}.$



n Items that should not be stowed in the bottle holders

Put the cap on before stowing a bottle. Do not place open bottles in the bottle holders, or glasses and paper cups containing liquid. The contents may spill and glasses may break.

Auxiliary boxes

Type A (if equipped)



Press in the lid. This box is useful for temporarily storing sunglasses and similar small items.

Type B (if equipped)



Press the button.

A CAUTION

n Items that should not be left in the auxiliary box (overhead type)

Do not leave glasses or lighters in the box.

If the interior of the vehicle becomes hot, lighters may explode and glasses may warp or crack.

n Caution while driving

Keep the auxiliary boxes closed when not in use. In the event of sudden braking, an accident may occur due to an occupant being struck by an open auxiliary box or the items stored inside.